

# ELBEE

RADIO DE DUCHA

DR-1308

## MANUAL DE USUARIO

1. Retire la base redonda de la radio, inserte dos pilas AAA en la posición correcta según las indicaciones dentro del compartimiento y cierre la base.
2. Encienda la radio girando el disco frontal (1). Sirve también para ajustar el volumen.
3. Para elegir la emisora deseada presione el botón RESET (2) para llegar a la frecuencia más baja.
4. Presione el botón SCAN (3) una vez para encontrar la emisora.
5. Presionando el botón SCAN (3) repetidamente puede cambiar las emisoras. Si la radio no reproduce ninguna emisora más, significa que ha llegado a la frecuencia más alta disponible. Presione el botón RESET para empezar la búsqueda de nuevo.
6. Puede quitar la ventosa (4) de la pared tirando de la pestaña.

### **Instrucciones de seguridad**

1. No instale el aparato cerca de fuentes de calor como radiadores, estufas u otros aparatos (incluidos amplificadores) que produzcan calor. No coloque llamas, como velas encendidas, cerca del aparato.
2. Diríjase a personal cualificado para cualquier reparación.
3. Puede haber peligro de explosión si la batería se coloca incorrectamente. Sustitúyalas únicamente por el mismo tipo de baterías o equivalente.
4. Las baterías (batería instalada o pilas) no deberán ser expuestas a calor excesivo, luz solar directa, fuego o similares.

**Eliminación de residuos** - No deseche las baterías con la basura doméstica. La ley le obliga a reciclarlas. Puede desecharlas en los puntos de recogida públicos o en cualquier establecimiento dedicado a este tipo de producto. Para la protección del medio ambiente, no se debe desechar los aparatos al final de su vida útil junto con la basura doméstica. Utilice los puntos de recogida adecuados.





**SHOWER RADIO**

**DR-1308**

## **INSTRUCTION MANUAL**

1. Open the bottom round case of radio, insert 2 pieces of AAA battery, and then close it.
2. Turn on the radio by switching the power / volume control tune (1).
3. To choose a desired channel, press the RESET button (2) to set the frequency at the lowest setting.
4. Press the SCAN button (3) once to automatically search for a channel.
5. To select a desired radio channel, press the SCAN button (3) momentarily and pause listen to the channel. If you have not reached the desired channel, repeat these actions. Then, the radio will be automatically turned into the next radio channel with a strong signal. After you have pressed the SCAN button for a few times and you do not hear any sound from the radio, the radio has reached the highest frequency. Press the RESET button to start tuning.
6. Big suction cup (4) for mounting on the window / glass, and air release by pushing the leg on suction.

### **Important Safety Instructions**

1. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat. Do not place the device near flames.
2. Refer all servicing to qualified service personnel.
3. There is a danger of explosion if battery is incorrectly replaced. The batteries should be replaced only with the same or equivalent type.
4. This device and batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire, or the like.

**Disposal** - Batteries do not belong in household waste. As a consumer, you are required by law to recycle used batteries. You can recycle your old batteries at public collection points or wherever the product was sold. For environmental reasons, do not dispose of the device in the household waste at the end of their service life. Dispose of the unit at a suitable local recycling point.